

Simplicity[®] Intelli-Comfort[™] CONTROL

THE Simplicity[®] Intelli-Comfort[™] CONTROL

INTRODUCTION AND OVERVIEW

Welcome to the new Intelli-Comfort[™] Control, a digital control system designed specifically for the 3 thru 25 ton single package rooftop units. The control logic of Intelli-Comfort[™] extends beyond current control capabilities.

The Intelli-Comfort[™] digital control performs all of the control and monitoring functions that were originally done by separate discrete relays, controls, interlocking hardware, and a Thermostat. This reduces manufacturing, service, and maintenance costs. The Intelli-Comfort[™] digital controller includes sophisticated control of the individual components of the HVAC cooling/heating unit, and has built-in rules that protect those components and optimize the control to its environment. The cooling and heating modes are protected against short cycling, slugging, multiple restarts, etc.

In the Intelli-Comfort[™] control, there are:

- a list of user-selected option settings and setpoints recorded within the control;
- inputs monitored by the Intelli-Comfort[™];
- specific fixed rules and timings built in to the control
- outputs to compressors and heat via the Simplicity[®] control, economizers, and other options.

Intelli-Comfort[™] has a real-time clock function, with minimum of ten hours 'Time-of-day retention' with unit power off.

If connected to a network, the control requests an address by a press of the Address button.

DIAGNOSTICS VIA LED

There is an LED on the board that shows the status of the control and alarms (see Status LED Table).

When the Alarm button is pressed and released one time within five seconds, it will re-enunciate the last five Alarms.

When this button is pressed and released two times within five seconds, it will clear all stored alarms.

The error details for most conditions are stored in summary in the Intelli-Comfort[™] Control, along with all data and can be accessed by a personal computer interface, or Palm Pilot (Some interfaces still in development).

Diagnostics may require patience due to internal timings. Normal observable conditions are the same - contactor 1M pulled in, compressor 1 running - but the control does not identify what it has just done or is about to do. The Intelli-Comfort[™] control will take action according to its internal rules. A call for cooling, for example, will be compared with supply air temperature before energizing a cooling stage.

ERROR HISTORY

The Intelli-Comfort[™] control stores up to 5 of the most recent alarms in a First In, First Out (FIFO) manner. As the control collects alarms, it will overwrite the oldest alarm after the history buffer becomes full.

Some system errors will initiate a controlling response as well as being stored in the error memory buffer. See the "Troubleshooting" chapter in this manual for a detailed description of how controller errors are handled.

Data items stored for maintenance / run history, in addition to Alarms:

- Accumulated run times for each compressor and heat stage
- Unit model number
- Unit serial number
- Unit Name

DIGITAL LINGO

This training manual is intended to help you with the commissioning process by illustrating the use of tools such as the control's digital input and software engineered specifically for starting up and servicing a rooftop unit.

You should become familiar with some common terminology and lingo used in the digital controls industry.

If this is your first exposure to the world of digital controls you may experience a lot of new terms, acronyms and technical lingo commonly used in the controls industry. For example, the Intelli-Comfort[™] input and output hardware points are described as **analog**, relating to a continuous scale of value readings such as a temperature sensor ranging from -40°F to 160°F range, or **binary**, meaning 2- states, either on or off, open or closed, true or false, one or zero. The term "digital" also means two states and its use is often interchanged with "binary". These points may be either factory- or field-set.

ANALOG TO DIGITAL CONVERTER

Computers can only understand a simple binary language. Remember, “binary” means two states - ON or OFF. Analog (continuous) values of voltages, currents, and resistances are supplied by sensors and transducers to the control. These values must be converted in to a binary code so that the computer can understand them. This conversion process is performed through a combination of hardware and software. For example, the 0-5VDC analog value from a static pressure transducer is divided into thousands of steps with a binary coded number, often called “counts”, assigned to each step...




FIGURE 1 - ANALOG TO DIGITAL CONVERTER

SOFTWARE TERMINOLOGY

A digital controller handles its control functions through software programming rather than with interlocking hardware and wiring. The software then becomes key to how controlled functions are handled. Software is a set of statements (referred to as the “program”) that define the function of the controller’s internal microprocessor computer.

Software procedurally tells the computer the sequence and order of tasks that need to be performed using a language that the computer can understand.

Software is stored in several types of computer memory. Each type has a specific function to perform.

EPROM - This is “non-volatile” memory, meaning it will not be erased on a power loss. This memory is usually programmed prior to assembly of the controller. Since this memory is not changed during normal operation of the *Intelli-Comfort™*

control, only basic operation instructions are stored in this type of memory.

EEPROM (Double “E” Prom) - is also non-volatile, but this type of memory requires a special process to be written. This memory can be written to and changed by the microprocessor. This is the type of memory that the control program is stored in the *Intelli-Comfort™* control.

FIRMWARE - “Firmware” is software, program instructions, or applications, and stored in EPROM or EEPROM memory.

RAM - Random Access Memory is a volatile memory. It will be erased when a power fail occurs. This memory is used as a kind of “scratch pad” for the controller. Temporary instructions and information such as an output controlling action like driving the economizer dampers open is stored here. When a power loss occurs or if the controller is sent a manual reset using a control pushbutton, this memory is cleared and initialized.

FAULT TOLERANCE - Fault Tolerance of the *Intelli-Comfort™* control involves two issues: Hardware fault tolerance deals specifically with the electrical characteristics of the controller - how much overvoltage or power surge the controller can withstand before damage occurs, and whether internal comparisons are verifying that the control is calculating and communicating properly. Software fault tolerance in this technology consists of comparing results to previous values and to reasonable values.

COMMUNICATIONS BUS

Networked communications may also be new to you. It relates to connecting several *Simplicity®* rooftop units to a network that can be monitored and controlled remotely from network computer workstations. You will find this typically on large installations where central control, monitoring, and energy management issues become a critical factor in operating a large complex such as a manufacturing facility.

The *Intelli-Comfort™* Control has the ability to be networked into a larger system using the MODBUS communication protocol. A communication protocol is simply a set of rules that determine how two systems communicate with each other over some medium such as a pair of wires, phone line, radio waves, etc. The transmission medium may also be called a gateway, pathway, or bus. An “open” protocol such as MODBUS is a publicly published set of rules that any equipment manufacturer can use to network into another manufacturer’s equipment.

COMPONENT DESCRIPTION

This section describes the main components of *Simplicity®* *Intelli-Comfort™* control. These components consist primarily of controllers, hardware to handle signal inputs and control outputs.

THE Intelli-Comfort™ CONTROLLER

Intelli-Comfort™ is a proprietary, microprocessor-based controller for use in HVAC applications. The controller provides monitoring and control for a total of 22 outputs.

WIRING AND TERMINATION, COMMUNICATIONS

Most connections to the Intelli-Comfort™ Control are by wiring harnesses. There are also screw terminal connections for thermostat inputs and for communications via an RS-485 port. However, Intelli-Comfort™ should not be installed with a thermostat. It is designed to replace the thermostat's function. The thermostat input screw terminals should be used only for testing and troubleshooting.

COMMUNICATION ADDRESS

The communication address button is used to identify a Simplicity® rooftop unit to a network, and "capture" the next available network address for that unit. Intelli-Comfort™ can be networked together for centralized monitoring and control. Much like we need a unique street address in our homes so we can receive our postal mail or emergency services, these units also need a unique address so the central Facilities Management System (FMS) can communicate to each unit individually.

ACRONYMS

A number of acronyms are used throughout this training manual. These are specific to the Intelli-Comfort™ control. They are also used in the Technical Guide and Installation and Operation manuals. Acronyms are used to refer to input and output hardware points and software parameters such as timing delays and setpoints.

INPUTS

There are two types of hardwired input points on the Intelli-Comfort™ control: Analog and Binary. These may be sensors, feedback, or adjustable setpoints. Typical analog inputs [AI] include Space Temperature (ST), Supply and Return Air Temperatures (SAT, RAT), and Building Pressure Sensor (BPS). The binary inputs (BI) on the Simplicity® Intelli-Comfort™ use a dry contact input to determine the status of a monitored point. Typical BI points are Fan Status (APS), Filter Status (DFS), and Compressor Status (HPS1-2, LPS1-2, C1O-2O).

ANALOG INPUTS (AI)

Analog inputs require parameters that define the input's characteristics. Attributes of an AI include the linear range, alarm limits, alarm differential, and change of state (COS) enable. The input values may be overridden by an external system command or by using the input buttons on the Intelli-Comfort™ board. This is useful to override current conditions to test certain control functions or modes.

BAS - Economizer override; if this option is enabled, an external BAS system will control the economizer 2-10 VDC signal through this pair of terminals.

ST - Space Temperature sensor is a field installed sensor (PN: 025-38928-000 - w/ Override Button).

SSO - Space Temperature Adjust is field installed. It is a slide adjustment located on a space sensor (PN: 025-38927-000) with a slide bar potentiometer. It is used to offset the space temperature setpoint. This slide-bar is a 20K ohm potentiometer. The programmable range for the Setpoint adjust is +/- 5°F. For example, if the Space Temperature setpoint is set to 74°F, the SSA is programmed to +/- 3°F and the SSA is adjusted fully to the + position, the new controlling space setpoint will be 77°F.

OAT - The outside air temperature sensor (PN: 031-01916-000A) is a factory-installed 10 K NTC sensor. Its range is from -50°F to 250°F.

OAH - Outside Air Humidity sensor, provides a 0-10 VDC signal to the controller over a range of 0 to 100% relative humidity. This input is used for the economizer calculation to determine whether free cooling is available and to switch between minimum outside air and using outside air as the first stage of cooling.

SAT - Supply Air Temperature sensor (PN: 031-01915-000A) is a factory-installed - 50°F to 250°F, 10 K NTC sensor.

RAT - Return Air Temperature sensor (PN: 031-01917-000A) is a factory-installed - 50°F to 250°F, 10 K NTC sensor.

RAH - Return Air Humidity The control will calculate the return air enthalpy using the relative humidity and return temperature inputs.

LOW VOLTAGE DETECTION - This input monitors the 24 VAC for low voltage conditions. The input has two thresholds, one at 16 VAC and one at 19.2 VAC. If the control needs to turn on a contactor, it will look to see if the voltage is above 19.2 VAC before it will turn it on. If the voltage is not above 19.2 VAC, it will hold off the contactor and flash the appropriate flash code. This flash code is not an alarm. If the control already has contactors pulled in, it will monitor the voltage and drop the contactors and shut down if the voltage drops below 16 VAC and flash the appropriate flash code.

SPC TEMP - offset value from the space sensor offset potentiometer.

DEMAND VENTILATION / IAQ - Indoor Air Quality. The IAQ expects a 0-10 VDC signal to the control from a field supplied and installed Carbon Dioxide (CO₂) sensor. Indoor air quality is monitored for adequate ventilation. In Demand Ventilation Mode, as the CO₂ levels in the building rise above the programmed setpoint, more fresh air must be brought in. The economizer is therefore adjusted to a more open position as

necessary. The linear ranging for IAQ sensor input is from 0 to 10,000 ppm. The Demand Ventilation setpoint is adjustable from 0 to 2000 ppm and is set at the factory at 1000 ppm.

DIFFERENTIAL DEMAND VENTILATION / IAQ - Outside IAQ sensor The control can operate with the Outside IAQ sensor and the inside IAQ sensor to provide Differential Demand Ventilation. This means it will operate to a setpoint based on the difference between outside and inside CO₂ levels.

BINARY INPUTS (BI)

APS - Supply Fan status is monitored by an Air Proving Status switch (which is a field installed option). The APS monitors the difference in pressure between the suction and discharge of the fan.

PURGE - This signal represents Building Purge (P) calls from an external source. If an external source is wired to the system, this input is connected to the board via screw terminals. This signal is loaded with a resistor to maintain voltage levels and to prevent "floating" of signals.

FILT - Dirty Filter switch (customer supplied, field installed) on factory-provided harness connections input to provide a filter status to the control. The control will alarm only after 24V has been sensed for ten minutes.

OUTPUTS

ANALOG OUTPUTS (AO) - Analog outputs provide a 2-10 VDC signal to operate controlled devices. The Intelli-Comfort™ is currently configured to use only 2-10 VDC output to the Economizer Damper. Since this output is analog, it is continuous between 2 and 10 Volts and is proportional to the 0 to 100% drive position of the device.

ECO - Economizer Actuator - The modulating Economizer uses a Belimo spring-return actuator. This actuator uses a 2-10 VDC signal to drive the dampers open. The actuator drives 95 degree rotation.

W1 and W2 - Heating calls - These are 24vac switched by two onboard relays that drive the heat through the Simplicity® board.

Intelli-Comfort™ PROGRAMMING OPTIONS

The paragraphs below provide a definition of, and specify the function related to, each of the parameters that are field-adjustable using the interfaces available. The Simplicity® Unit is shipped from the factory with the necessary options pre-programmed as indicated by the model nomenclature. It is always a good practice, though, to verify that the correct parameters are properly configured for the unit you are commissioning. You can find a complete list of field-adjustable parameters in the "**Settable System Parameters**" section.

INTERACTING THROUGH THE Simplicity® Intelli-Comfort™

INITIAL STARTUP OPTIONS

Commissioning a new Simplicity® installation requires some field adjustments to the Intelli-Comfort™ control program. Most of these adjustments simply involve setting up the various setpoints that are specific to your customer's needs (i.e. economizer minimum position) or enabling some extended options that are integrated into the Intelli-Comfort™ control.

METRIC OPERATION (ENGLISH)

The factory default for this option is OFF. The metric (SI) conversions are part of the PC software; when the Metric parameter is selected, temperature setpoints and readings will convert to Centigrade (°C).

SETTABLE SYSTEM PARAMETERS

The following headings list each parameter's name and its default setting. The control is set at the factory for the options of the specific unit; if a replacement control is being installed, the entire parameter set must be matched to the unit. The value in (parentheses) is the value of a parameter in an unconfigured control.

COMPRESSORS - (2) - This tells the control the number of compressors available. The Factory Default [the value in an unconfigured replacement control] is 2 and can be adjusted from 1 to 2.

SAT CONTROL FOR COOLING - (ON) - This tells the control if it is going to do excessive SAT monitoring and tripping or not, for Cooling. The SAT should be maintained in an acceptable range in order to achieve reliable compressor operation. The compressor trip limits are user adjustable between 40°F and 65°F in one degree increments. The default cooling trip limits are 50°F for stages 1 - 2. When the SAT drops below the trip limit for each respective compressor, that compressor is locked out and a 5 minute ASCD is initiated for that compressor. If this option is enabled, remember to set the compressor cooling limits for low limit trip.

ECONOMIZER - (ON) - Identifies there is an Economizer Installed.

ECONOMIZER MIN POSITION - (20%) - Identifies the minimum outdoor damper position that will be used for the Occupied mode. Adjustable from 0-100%, the Economizer Minimum Position default is 20%.

ECONOMIZER FIRST STAGE SETPOINT - (55°F) - Identifies what Supply Air Temperature to maintain for a call for first stage of cooling. This is used in cooling mode with Economizer operation. The setpoint is set at 55°F with an adjustable range from 40°F to 65°F.

ECONOMIZER SECOND STAGE SETPOINT - (50°F) - Identifies what Supply Air Temperature to maintain for a call for second stage of cooling. This is used in cooling mode with Economizer operation. This setpoint is set at 50°F with a range from 40°F to 65°F.

OUTSIDE AIR HUMIDITY (OAH) SENSOR ENABLE - (OFF) - Identifies the control is expected to use Outside Air Enthalpy (calculated from Outside Air Temperature and Outside Air Relative Humidity sensed values) to determine if Outside Air can be used for cooling.

The control is self-configuring to the best available decision strategy for free cooling availability. For example, if it detects that OAT and OAH and RAT and RAH sensors are all connected and reliable, it can be configured for Differential Enthalpy operation. If one of the return air sensors should fail, the control will reconfigure for Outside Enthalpy operation, etc.

If the OAH Sensor Enable option is turned ON, it means that the Outside Enthalpy Operation, or better decision strategy, is expected (and supported by installed sensors). If the appropriate sensors are not installed, or one of them failed, a sensor failure alarm is set. The alarm can be turned off by turning off the OAH Sensor Enable option. Thus, the option setting is used to reflect the desired operation and mainly to control sensor failure alarms.

The option setting can be viewed as specifying that the self-configured economizer decision strategy has to be at least this, or better, otherwise an alarm is set. If the option is OFF, the control still may self configure to Outside Enthalpy Operation, or even to Differential Enthalpy Operation (if all needed sensors are available), but this option setting will also allow the decision strategy based on only OAT (in case other sensors fail, or are not installed) without setting an alarm.

OUTSIDE AIR ENTHALPY SETPOINT - (27 BTU/LB) - Identifies the outside air enthalpy limit. Below this limit, outside air is available for cooling. See enthalpy chart. This parameter uses a one BTU/LB hysteresis on each side of the limit. The setpoint is preset to 27 BTU/ LB with an adjustable range from 10 to 50 BTU/LB.

RETURN AIR HUMIDITY (RAH) SENSOR ENABLE - (OFF) - Identifies that the control will compare Outside Air Enthalpy (calculated from Outside Air Temperature and Outside Air Relative Humidity sensed values) and Return Air Enthalpy (calculated from Return Air Temperature and Return Air Relative Humidity sensed values). The control will use the air stream with the lower enthalpy for cooling.

The control is self-configuring to the best available decision strategy for free cooling availability. For example, if it detects that OAT and OAH and RAT and RAH sensors are all connected and reliable, it can be configured for Differential Enthalpy operation. If one of the return air sensors should fail,

the control will stop using rules that involve RAH and set an alarm.

If the RAH Sensor Enable option is turned ON (and supported by installed sensors), Differential Enthalpy Operation can be enabled. If the appropriate sensors are not installed, or one of them failed, a sensor failure alarm is set. The RAH alarm can be turned off by turning off the RAH Sensor Enable option. Thus, the option setting is used to reflect the desired operation and mainly to control sensor failure alarms.

ECONOMIZER LOADING TO CONTROL SAT - (ON) - Identifies if the control is going to use Economizer Loading to control excessive SAT [supplying warmer outside air to keep SAT from going too low]. This parameter is only applicable outside the normal Economizer operation. During the Economizer operation, the loading function is always performed and is an integral part of the control algorithm.

OCCUPIED - (from settings in Weekly Schedule and Holiday Schedule Tables.) See discussion in Sequence of Operation.

UNOCCUPIED - (from settings in Weekly Schedule and Holiday Schedule Tables.) See discussion in Sequence of Operation.

COMFORT VENTILATION MODE - (OFF) - Comfort Ventilation is a SAT control mode that controls SAT during “satisfied” periods in a fairly wide temperature band, using mostly Outside Air, and also cooling and heating stages as necessary.

To enable Comfort Ventilation, the programmable parameter “Comfort Ventilation Mode” must be set to ON (default setting is OFF).

For a detailed explanation of Comfort Ventilation, refer to the Sequence of Operation in this manual.

COMFORT VENTILATION HIGH SUPPLY AIR SETPOINT - (80°F) - Identifies the High Limit Setpoint for the Comfort Ventilation mode. For a stable operation of Comfort Ventilation function, the High Supply Air Setpoint should be set 10.0°F or more above the Low Setpoint.

COMFORT VENTILATION LOW SUPPLY AIR SETPOINT - (70°F) - Identifies the Low Limit Setpoint for the Comfort Ventilation mode. For a stable operation of Comfort Ventilation function, the Low Supply Air Setpoint **should be set 10.0°F or more below the High Setpoint.**

DIRTY FILTER SWITCH - (OFF) - Identifies a Dirty Filter Switch is connected to the control. The control will wait for ten minutes after the switch has closed before declaring a Dirty Filter Alarm. The alarm is written to the Error History Buffer. In networked applications, the error flag is readable by the network. The alarm will automatically reset when the error condition is corrected.

HEATING LOCKOUT ON OAT - (75°F) - Identifies the Outside Air Temperature Setpoint the control will use to lock out Heating when the OAT is above this setpoint. There is a one-degree hysteresis on each side of the setpoint. This parameter is adjustable between 0°F and 100°F with the default set to 75°F.

NOTE: A Heating Lockout on OAT may occur while the control is in a heating mode and there is a demand for heating.

If the OAT then decreases below the lockout setting while the call for several heat stages exists, the heat stages will turn on simultaneously. This is considered acceptable as this situation is not expected to occur frequently.

COOLING LOCKOUT ON OAT - (45°F) - This is the Outside Air Temperature Setpoint that the control uses to lock out Cooling when the OAT is below this setpoint. Adjustable from 0°F to 100°F, the default is 45°F.

UNOCCUPIED HEATING SETPOINT - (60°F) - Identifies the Unoccupied Heating Setpoint. It controls Unoccupied heating with the Space Sensor.




FIGURE 2 - SEQUENCE OF SETTING THE SET POINTS

The control will attempt to correct wrong temperature overlap settings; for example, if a change is made that would put Occupied Heating above Occupied Cooling, the Occupied Cooling setting will change to stay above the heating setpoint.

OCCUPIED HEATING SETPOINT - (68°F) - Identifies the Occupied Heating Setpoint. Its relationship to the related setpoints is as defined in the Unoccupied Heating Setpoint paragraph above.

UNOCCUPIED COOLING SETPOINT - (85°F) - Identifies the Unoccupied Cooling Setpoint.

OCCUPIED COOLING SETPOINT - (72°F) - Identifies the Occupied Cooling Setpoint.

SUPPLY AIRTEMP (SAT) ALARM SETPOINT FOR COOLING - (0°F) - If the SAT does not drive below this setpoint when all stages of compression are operating and 10 minutes has elapsed since the last compressor was energized, the control will declare a Cooling SAT Failure Alarm.

The alarm is written to the Error History Buffer. In networked applications, the alarm flag is readable via the network.

The alarm will reset automatically if the SAT decreases below the setpoint (the alarm condition no longer exists), or when a compressor is turned off (the control does not request all compressors operate). The SAT Alarm Setpoint for Cooling can be adjusted from 50°F - 80°F. If the value is set to 0°F (default) this feature is disabled.

Before the control declares an error, it will read the OAT and the Economizer position. If the OAT is more than 20°F warmer than the setpoint and the Economizer is open more than 20%, the control will close the Economizer for 10 minutes and then read the SAT. If the SAT falls below the setpoint, the control will declare an Economizer Minimum Position alarm. The control will keep the Economizer closed and finish the Cooling mode. After the Cooling mode has been satisfied, the control will move the Economizer back to the minimum position.

SUPPLY AIR TEMP (SAT) ALARM SETPOINT FOR HEATING - (0°F) - The SAT must rise above this setpoint when all stages of heating are operating and 10 minutes has elapsed since the last stage was energized. If this does not happen, the control will declare a Heating SAT Failure Alarm. The alarm is written to the Error History Buffer. In networked applications, the alarm flag is readable via the network. The alarm will reset automatically if the SAT increases above the setpoint (the alarm condition no longer exists), or when a heating stage is turned off (the control does not request all heat stages to operate).

The SAT Alarm Setpoint for Heating can be adjusted from 70°F - 120°F. If the value is set to 0°F (default) this feature is disabled.

Before the control declares an error, it will read the OAT and the Economizer position. If the OAT is more than 20°F colder than the setpoint and the Economizer is open more than 20%, the control will close the Economizer for 10 minutes and then read the SAT. If the SAT rises above the setpoint, the control will declare an Economizer Minimum Position alarm. The control will keep the Economizer closed and finish the Heating mode. After the Heating mode has been satisfied, the control will move the Economizer back to the minimum position.

UNOCCUPIED OVERRIDE TIME PERIOD - (60 min) - The Unoccupied Override Time Limit function will determine how long the unit will operate in the Unoccupied Override mode when the Override button is pressed on the Space Sensor.

Once the Unoccupied Override mode is initiated, it will continue until the programmed Unoccupied Override Time Limit is reached. The Override mode cannot be cancelled by, for example, a change of state of the Occupied input to ON (occupied) and then back to OFF (unoccupied).

This parameter is adjustable from 0 to 240 minutes. The default is 60 minutes.

If the control senses this input along with a Y signal, it will not turn on the compressors and it will run the Heating mode. Heating takes priority over cooling.

FAN ON MODE WITH THE SENSOR OPTION - (ON) - When this option is turned ON, the supply fan will continue running when the zone sensor based temperature control is satisfied. This option applies only in systems using a zone sensor and only in Occupied mode. With this option turned OFF, or in Unoccupied mode, the fan will go off when the zone sensor based temperature control is satisfied and will go on only when there is a call for heating or cooling. Turning this option ON is an equivalent of selecting fan ON (rather than AUTO) in systems with a thermostat. In a thermostat system, the fan control follows the thermostat's G signal. In sensor systems and in the Occupied mode, the fan control follows the Fan ON Mode option.

SPACE SENSOR ENABLE - (OFF) (INTERNALLY SET) - The control will use this input if it detects the device.

RAT SENSOR ENABLE - (OFF) (INTERNALLY SET) - The control will use this input if it detects the device.

DEMAND VENTILATION (ON) - Setting this parameter on tells the control to expect a signal from a 0-10VDC CO₂ sensor. The default setting for CO₂ is 1,000 ppm.

DEMAND VENTILATION SETPOINT - (1000 ppm) - Identifies the maximum Indoor Air Quality (IAQ) level that the control will allow. It is adjustable from 700ppm to 1500ppm.

IAQ SENSOR RANGE - (5,000 ppm) - Identifies the full range is for a specific IAQ sensor. It can be changed from 0 to 10,000ppm.

COOLING MODE ENABLE (ON) - Identifies if the control has Cooling Available (Mode Switch). If this option is turned off, cooling operation is disabled. Note that this parameter does not affect cooling operation in Comfort Ventilation mode.

HEATING MODE ENABLE - (ON) - Identifies if the control has Heating Available (Mode Switch). If this option is turned off, heating operation is disabled. Note that this parameter does not affect heating operation in Comfort Ventilation mode.

SPACE SETPOINT OFFSET - (3°F) - The Space Setpoint Offset is the +/- value the control will use to offset the Space Setpoint when the sidebar Space Sensor is used. For example, if the Space Setpoint Offset value is set to 3.0°F, shifting the sidebar all the way in minus direction will decrease the Space Setpoint by 3.0°F and shifting it all the way in plus direction will increase the Space Setpoint by 3.0°F. It is adjustable from 0°F to 5°F.

SEQUENCE OF OPERATION FOR Intelli-Comfort™ CONTROLS

This chapter describes the many control modes of operation for Intelli-Comfort™. Because of the narrative and detailed descriptions contained in this section, you should scan this chapter and become familiar with the primary topics. Then, use this chapter as a reference whenever a more detailed understanding of a particular mode is needed.

Keep in mind, with digital controls interlocking between control modes is common and easily achieved. Also, by the very nature of digital control programming, many simultaneous rules can be implemented because they generally require only software programming and very little peripheral hardware. This reduces the costs associated with manufacturing and servicing equipment with this level of interacting features but you can't see the status of interlocked rules as you can with discreet relays.

Several control modes will override other modes of operation.

For example; The Demand Ventilation (or, Indoor Air Quality) control may override Comfort Ventilation / Economizer control and drive the OA dampers above the established minimum position. The Excessive SAT control will override all temperature control modes, Economizer mode, and compressor operation as well. If you suspect that a problem exists with the economizer, or the compressors are locked out when no alarms are set, verify that one of the control modes is not overriding the normal mode of operation or the operation you might expect to see.

AIR PROVING SWITCH - When the control starts the supply fan, it waits 90 seconds to check for closure of the Air Proving Switch. If the APS does not close, the control will turn off all outputs and flag an alarm, and flash an alarm on the display.

It will retry the Fan output every 30 minutes for three attempts. If after three attempts it still cannot qualify the Fan, it will alarm and lock all heating and cooling operation out. If the switch closes after an alarm has been flagged, the control will resume normal operation and clear the active alarm.

After the control has turned off the fan, it will wait 90 seconds and verify that the switch opens. If the switch does not open after 90 seconds, the control will flag a failed switch and flash the alarm. On the next startup, the control will stage up equipment normally.

This switch-closed failure mode of the Air Proving Switch can only be detected with the Supply Fan off. It is important to detect because it effectively disables the fan failure alarm checking while fan is running, described in the paragraphs above. Those checks would always pass as the switch would remain closed. In networked applications, the error flag is readable by the network. The alarm will automatically reset after the problem that caused it has been corrected.

When the control is running the fan and the APS has already been proven, and then it opens, the control will wait 2 seconds before shutting down heating, cooling, and locking out. It will alarm and retry as if it happened during start-up.

FAN DELAYS - There are separate Fan ON and OFF delay periods for heating and cooling, to reduce the momentary change in SAT.

COMFORT VENTILATION MODE




FIGURE 3 -COMFORT VENTILATION ECONOMIZER CONTROL

Comfort Ventilation is a control mode that uses the economizer to modulate SAT. Where possible, the economizer will modulate the outside / return air mix to keep SAT within the upper and lower Comfort Ventilation setpoints. The control will modulate the economizer, and energize cooling or heating, to keep SAT within the Comfort Ventilation setpoints, even though space temperature may be satisfied. For example, minimum economizer position can take SAT out of the Comfort Ventilation range, requiring heat or cooling that the thermostat isn't calling for.

The result of comfort ventilation control is less variation of SAT, and fewer on-off cycles of mechanical cooling or heating.

If turning off a cooling stage raises SAT above the upper setpoint, but leaving it running will take SAT below the lower setpoint - then the compressor is left on, and warmer outside air is brought in to raise SAT to the lower setpoint to keep a compressor from cycling off. Similarly, if leaving a heat stage on will raise SAT above the Upper setpoint, the control will leave heat on and modulate cooler outside air into the airstream to maintain proper SAT.

The Comfort Ventilation temperature-band minimum width is five degrees. Comfort Ventilation high and low setpoints will be within the Cooling Upper and Heating Lower setpoints.

Without using the Comfort Ventilation mode where available, when the space temperature control loop is satisfied (zero demand), all cooling and/or heating stages would be turned

off and the SAT would be allowed to float until the space temperature control loop again generates a call for cooling or heating. The supply fan may be kept on during the "satisfied" periods, or may be turned off, depending on thermostat settings, or "Fan ON mode with the Sensor" option setting. If Comfort Ventilation is selected, it will take priority over supply fan control and keep it running during the "satisfied" periods, when there is no call for heating or cooling.

The Comfort Ventilation mode is used to optionally replace the uncontrolled, floating SAT situation during the "satisfied" periods with a "loose" SAT control in a fairly wide temperature band (between specified Comfort Ventilation Upper Setpoint and Comfort Ventilation Lower Setpoint). This may require some additional energy, but improves space comfort (e.g. instead of bringing a very hot and humid ventilation / outdoor air into space during the "satisfied" periods, the ventilation air temperature is "trimmed" to be within the specified SAT control band).

Comfort Ventilation mode terminates when there is a call for heating or cooling from the space temperature control.

- Comfort Ventilation can be used only on units equipped with an Economizer.
- Comfort Ventilation only operates in an Occupied mode.
- "Comfort Ventilation Mode" must be set to ON (default setting is OFF).

The modulating range of the economizer dampers are limited by a specified Economizer Minimum Position and by a specified Comfort Ventilation Maximum Economizer Setpoints.

The Economizer capability to control SAT may be further limited in case the Demand Ventilation Operation is enabled and overrides the economizer to a more-open position in order to satisfy space IAQ requirements. The values of "Comfort Ventilation Upper Setpoint" and "Comfort Ventilation Lower Setpoint" would typically be set such that they are centered around an expected return air temperature. The band between the two setpoints should be set wide enough so that SAT changes due to staging / destaging compressors, or heating stages, can be compensated for by the economizer control so that staging / destaging is minimized. Also, a wider band minimizes use of additional energy during unit's "satisfied" periods.

ECONOMIZER CONTROL DURING COMFORT VENTILATION - Economizer control uses a Proportional-Integral (PI) control algorithm that maintains SAT within the specified SAT band by modulating the economizer dampers. The PI algorithm setpoint is calculated as a midpoint between the programmed "Comfort Ventilation Upper Setpoint" and "Comfort Ventilation Lower Setpoint". As the controller uses outside air to maintain the SAT at the setpoint, it must be capable of self-configuration for Direct or Reverse action, depending on the relationship of the OAT to the specified SAT control band:

- If the OAT is below the specified SAT band low setpoint ("Comfort Ventilation Lower Setpoint"), the action is Direct Acting. In this case, the economizer control can lower the SAT temperature just by opening the economizer damper and using more outdoor air. However, if the economizer algorithm cannot prevent the SAT from dropping below the bottom control band limit by closing the economizer damper to its programmed minimum position, one or more heating stages may need to be turned on. Similarly, if the economizer algorithm cannot prevent the SAT from increasing above the top control band limit, one or more compressors may need to be turned on.
- If the OAT is above the specified SAT band high setpoint ("Comfort Ventilation Upper Setpoint"), the action is Reverse Acting. In this case, the economizer control can increase the SAT temperature just by opening the economizer damper and using more outdoor air. However, if the economizer algorithm cannot prevent the SAT from increasing above the top control band limit by closing the economizer damper to its programmed minimum position, one or more compressors may need to be turned on. Similarly, if the economizer algorithm cannot prevent the SAT from dropping below the bottom control band limit by opening the economizer damper, one or more heating stages may need to be turned on.
- If the OAT is within the SAT control band, i.e. between the programmed "Comfort Ventilation Upper Setpoint" and "Comfort Ventilation Lower Setpoint", the economizer damper is driven to the fully open position. In this case, no other control action needs to be taken to maintain the SAT within the specified control band.

STAGING CONTROL DURING COMFORT VENTILATION

The economizer control alone may not be able to maintain the SAT within the specified control band. A separate staging control algorithm supplements the economizer control and will stage heating, or mechanical cooling as necessary.

If the SAT increases above the "Comfort Ventilation Upper Setpoint" for more than 5 minutes, the control will destage a heating stage, or add a compressor. The control will repeat this process every 5 minutes until the SAT gets back to within the control band.

If the SAT drops below the "Comfort Ventilation Low Supply Air Setpoint" for more than 5 minutes, the control will destage a compressor, or add a heating stage. The control will repeat this every 5 minutes until the SAT gets back to within the control band. As the heating stages, or compressors are staged, or destaged, the economizer control continues using the economizer damper to "trim" the effect of the staging and to maintain the SAT as near the middle of the SAT control band as possible.

CONTROL OPERATION

The paragraphs below identify control modes of operation and provide an overview of control methods in all modes. The modes include Occupied and Unoccupied Heating and Cooling, and differ depending on the method used to control zone temperature. The heating vs. cooling modes are entered under control of the scheduling, and the control algorithm detecting zone cooling or heating demand. The "occupied" vs. "unoccupied" modes are controlled by an internal time clock. If a thermostat input is connected, it takes priority over the space sensor algorithms.

ECONOMIZER MODE

With a cooling demand and when free cooling is available ("economizer suitable"), the SAT controlled by the economizer control algorithm (see section Economizer Operation later in this manual) and the control determines (by 1st and 2nd stage calls) the active economizer SAT setpoint. When the control is satisfied (Y1=OFF, Y2=OFF), then the unit either shuts down (if G=OFF) after the specified supply fan overrun time, or only the supply fan continues to operate if the Fan On Option is on.

NOTE: During Economizer operation using "Economizer First Stage Setpoint" for SAT control, one or more compressors may be running in addition to economizer damper partially, or fully open to provide free cooling. The number of compressors running will mainly depend on outdoor air temperature. Therefore, when the thermostat is satisfied and shuts down the cooling, it may be turning off more than one compressor (after compressor minimum run time expires).

This is acceptable and is not expected to occur frequently. See the section on Comfort Ventilation. If the outdoor air condition is such that more than one compressor is needed in addition to free cooling, the Economizer mode is likely to terminate and the unit will switch over to mechanical cooling only.

OPERATION FOR HEATING WITH W1 AND W2, OUTPUTS TO THE Simplicity® BOARD

W1 AND W2 outputs are available on the Simplicity® Intelli-Comfort™ board.

Three minute Minimum Run Time and two minutes minimum off time applies to all heat stages.

SENSOR OPERATION

Typically, a space sensor should be installed. The only exception should be for servicing or troubleshooting the unit. A service person may hardwire the thermostat inputs to check the equipment operation even if the unit is using a

space sensor. The thermostat input will have priority over the Space Sensor. A unit using a space sensor will switch to a thermostat control strategy automatically if a thermostat input is detected and switch back if the thermostat is no longer detected.

TYPES OF SPACE SENSORS

NO SENSOR- The system will internally detect the presence of space sensors.

SENSOR WITH UNOCCUPIED OVERRIDE BUTTON - This Sensor has a Thermistor and an Override button that when pushed, will place the unit in Unoccupied Override (Occupied mode) mode for the Unoccupied Override Time. Once the Unoccupied Override mode is initiated, it will continue until the programmed Unoccupied Override Time Limit is reached.

SENSOR WITH SPACE SETPOINT ADJUST - This Sensor has a slider potentiometer on it that represents (as a default) +/- 3°F adjustment to the Space Setpoint. The Space Setpoint Offset option. If the unit appears to be controlling at a higher or lower temperature than the setpoint, check the Space Setpoint Adjust slider.

SUPPLY FAN CONTROL WHEN USING A ZONE SENSOR

- In the Occupied mode, setting of the parameter "Fan ON mode with the Sensor Option" will determine if the Supply Fan is ON continuously or is in "Auto" mode (i.e. cycles with the heating/ cooling cycles). In Unoccupied mode, the fan is always in the Auto mode.

SUPPLY FAN OFF DELAY - Uses minimum off time.

CONTROL OF COMPRESSORS WHEN USING A ZONE SENSOR

- A Minimum run time of one to ten minutes [default = three] applies to all compressors. The minimum run time is necessary to ensure that the oil in the refrigerant circuit circulates back to the compressor.

The Anti Short Cycle delay of five minutes OFF applies any time compressor operation is terminated. Compressors are turned ON and OFF individually during CV operation with a zone sensor, where the cooling control algorithm is implemented in the controller (rather than in a thermostat).

There is a minimum 30 second delay between compressors when bringing on multiple compressors.

HEATING OPERATION - The space temperature is controlled to a programmed Unoccupied Heating Setpoint, or to a programmed Occupied Heating Setpoint, as determined by the internal schedule and the state of the Occupied flag from a BAS.

The control will use as many as two stages of heat, depending on what heat option is installed.

A zone heating demand of -1.5°F will generate a request for first stage heat.

A zone heating demand of -2.0°F will generate a request for second stage heat.

When the zone temperature is -0.1°F below the zone setpoint for at least 1 minute, the transition to a satisfied state occurs, the heating stops and the supply fan either continues running, or is turned off after the fan off delay. The supply fan control in the satisfied state and in the occupied mode is determined by setting of the programmable parameter "Fan ON Mode with the Sensor Option". In the unoccupied mode, the fan is always turned off when the zone is satisfied.

During heating, the SAT control to the selected SAT setpoint is performed. Two minute Minimum Run Time and Anti Short Cycle delays applies to all heat stages. There is also a delay of at least one minute between turning on heating stages.

COOLING OPERATION - The control will operate as a two-stage unit.

On two compressor units, compressor one is first stage and compressor two is second stage.

The control uses a minimum 30-second compressor delay between compressors when bringing on multiple compressors.

A zone cooling demand of 1.5°F initiates a call for first stage cooling.

A zone cooling demand of 2.0°F initiates a call for second stage cooling.

If the unit has a demand greater than 1.5°F but less than 2.0°F, the control will turn on stage one and initiate a 5-minute timer. If after 5 minutes the Space temperature is not moving toward the Setpoint, the control will turn on stage two and wait 5 minutes. The control will turn off the second stage compressor with a 30-second delay between them when the demand reaches 0.5°F. The control will continue operating first stage until the Space temperature reaches the Setpoint and then it will turn off the stage one compressor.

If the unit starts with a demand greater than 2.0°F, the control will initiate first stage and wait 5 minutes. The control will continue operating first stage until the Space temperature reaches the Setpoint and then it will turn off the stage one compressor. If after 5 minutes the Space temperature is not moving toward the Setpoint the control will initiate stage two and wait 5 minutes. The control will turn off the second stage compressor when the demand reaches 0.5°F with a 30 second delay between them. The control will continue operating first stage until the Space temperature reaches the Setpoint and then it will turn off stage one.

There are two different SAT control algorithms, one used when free cooling is available (economizer operation) and the other one for mechanical cooling only. These two SAT control algorithms are described in the Occupied Cooling section below. Since the economizer is not active in Unoccupied mode, this will be restricted to mechanical cooling.

CONTROLLING EXCESSIVE SAT (SUPPLY AIR TEMPERATURE)

This is required in cooling operation in order to prevent "slugging" and damage to the compressors. Some rooftop units do not use accumulators on compressor intake, and liquid refrigerant could enter the intake of a compressor in case of a low heat transfer on the evaporator coil. In heating operation, the Excessive SAT control is not used.

SAT CONTROL CONFIGURATION

SAT control for cooling is configurable to enable or disable (on/off). The default setting for cooling is ON. The user is not normally expected to turn this mode OFF, but the possibility of turning it OFF is provided mainly for troubleshooting purposes.

SAT CONTROL FOR COOLING

This control has priority over any other zone temperature or SAT control and is used at all times. The Excessive SAT Control state is entered any time the SAT drops below the trip point.

While in this state, the control will continue monitoring the SAT and turning off compressors any time the SAT drops below the trip point. There is a 2 minute time delay between compressor trips in cases when the SAT drops below trip point. This assures that multiple compressors will not be turned off simultaneously.

ECONOMIZER LOADING OPERATION DURING AN EXCESSIVE SAT FOR COOLING:

ECONOMIZER OPERATION

Economizer dampers allow mixing of outdoor and return air. The dampers are coupled and controlled with a single actuator such that when the Outdoor Air damper is fully closed, the Return Air damper is fully open (and vice versa). The position of the Economizer dampers are controlled based on:

1. Energy considerations ("free cooling")
2. Ventilation considerations (minimum Outdoor Air damper position and Demand Ventilation)
3. Space static pressure considerations (minimum Outdoor Air damper position).

Economizer dampers are also controlled in certain situations to perform "economizer loading" - which minimizes SAT temperature swings resulting from turning cooling or heating stages on / off. This function is separate from normal economizer operation and is described at the end of this section.

WHEN IS THE ECONOMIZER OPERATION USED?

If the rooftop unit is equipped with an economizer, and free cooling is available ("economizer suitable"), then the Economizer Operation as specified in this section will be used in the following operation modes:

MINIMUM VENTILATION POSITION SETTING

The minimum position setting represents the minimum opening of the outdoor air damper (% open). This setting will be maintained any time the unit is in Occupied mode. The minimum position setting will be determined by an "Economizer Min Position" programmable parameter set by a computer running the front-end software. The minimum position setting will be ignored during the Unoccupied mode. During the Unoccupied mode, the minimum position is 0% (the Economizer may not remain closed during the Unoccupied mode, in case the temperature control to an unoccupied setpoint can use Outside Air for free cooling).

MINIMUM POSITION DURING HEATING AND OCCUPIED MODE

During heating while in Occupied mode, the economizer will be at its programmed minimum position.

MINIMUM POSITION DURING COOLING AND OCCUPIED MODE

During cooling while in Occupied Mode, the economizer may be at its programmed minimum or may be modulated between its minimum position and 100% open position by the economizer control.

SAT SETPOINTS USED DURING COOLING WITH ECONOMIZER OPERATION:

As long as the Economizer Operation is enabled and "free cooling" is available, the economizer will be controlled (with, or without any compressors running) to maintain the following SAT setpoints: In CV cooling mode:

- With a call for first stage cooling, a programmed Economizer First Stage Setpoint. This setpoint is programmable in the range of 40°F to 65°F, default setting is 55°F
- With a call for second stage cooling, a programmed Economizer Second Stage Setpoint. This setpoint is programmable in the range of 40°F to 65°F, default setting is 50°F

CRITERIA FOR ECONOMIZER SUITABLE DECISION SENSOR AVAILABILITY:

There are three different methods of deciding whether the economizer is suitable:

- **Differential enthalpy** (highest preference from energy viewpoint)
- **Outside enthalpy** (middle preference) and
- **Outside temperature method** (lowest preference)

The choice of a method with highest preference is automatic (“self-configuration”) based on availability of appropriate sensors. If a sensor fails or is unreliable, a fault is indicated and the next highest preference method will be automatically selected (“fault tolerance”).

There are two ON/OFF programmable parameters related to the choice of an economizer method:

- “OAH Sensor Enable”
- “RAH Sensor Enable”

These parameters are set to reflect the installed sensors that can be used by the “self-configuration” feature and control sensor failure alarms.

The OAH sensor, if available, allows use of Outside Enthalpy method for deciding on free cooling availability.

The RAH sensor, if available in addition to the OAH sensor, allows use of Differential Enthalpy method for deciding on free cooling availability.

See paragraphs OAH Sensor Enable and RAH Sensor Enable in The Settable Parameters.

If the selected method is using an enthalpy, the enthalpy is calculated in the controller from sensed temperature and humidity of the respective air stream.

DIFFERENTIAL ENTHALPY METHOD: is set by parameter and used only when sensors for Outdoor Air temperature, Outdoor Air humidity, Return Air temperature and Return Air humidity are all installed and reliable.

OUTSIDE ENTHALPY METHOD: will be configured by setting ON the parameter for the Outdoor Humidity Sensor [OAH], and will be the default if the unit defined as Differential Enthalpy cannot read the Return Air Humidity sensor.

OUTSIDE TEMPERATURE METHOD: will be self-configured and used only when differential enthalpy or outside enthalpy methods are not available, and sensor for Outside Air temperature is installed and reliable.

Economizer is suitable when OAT is less than SAT setpoint + 10°F. Use a 2°F differential on both sides of this limit. As the

SAT setpoint value, use only one of the programmed 1st or 2nd stage economizer setpoints (depending on what cooling stage is called), not any transient setpoints that may be used temporarily during the staging process. Note that this rule does not reflect any consideration of geographical location and weather conditions, but rather reflects the average expected SAT temperature drop obtained from DX cooling stages, i.e. the highest outdoor air temperature that the DX cooling can still reliably reduce to the SAT setpoint.

OUTSIDE ENTHALPY METHOD: Economizer is suitable when OA Enthalpy is less than Outside Enthalpy setpoint and OAT is less than OAT Economizer Enable Setpoint: Use a 2°F and 1 BTU/LB differentials respectively on both sides of these limits. The Enthalpy number is a programmed parameter with a range of 22-40 BTU/LB, default 27 BTU/LB. The Enthalpy Number can be viewed as the maximum outdoor air enthalpy with which the outside air can still be considered suitable for DX cooling, or, in comparison to the Differential Enthalpy Method described below, as a “best guess” on actual return air enthalpy, which in this method is not being sensed. The temperature limit reflects the average expected SAT temperature drop obtained from DX cooling stages.

DIFFERENTIAL ENTHALPY METHOD: Economizer is suitable when OA Enthalpy is less than the RA Enthalpy AND OAT is less than SAT setpoint plus 10°F (+/- 2°F and 1 BTU/LB): Use a 2°F and 1 BTU/LB differentials respectively on both sides of these limits. This is similar to the Outside Enthalpy method, except instead of a programmed Enthalpy Number, an actually sensed return air enthalpy is used.

SAT CONTROL WITH ECONOMIZER - If the economizer is “suitable” (free cooling is available) and cooling is required, the algorithm will be active and modulate economizer position in order to control SAT to the active SAT setpoint. If the economizer is not suitable, the algorithm is deactivated and the economizer is placed at its programmed minimum position. The economizer control algorithm will typically be cycled ON/OFF several times an hour under control of a zone thermostat, or a zone sensor. A zone control algorithm will activate the economizer algorithm when cooling is required, and will switch between Economizer 1st and 2nd stage SAT setpoints, and will deactivate the economizer algorithm when the zone is satisfied.

The PI economizer control algorithm is always active during economizer operation (as long as economizer is “suitable”) and will control SAT to an active (1st or 2nd stage) Economizer setpoint. This means that this control loop not only modulates the Outside Air damper open to add free cooling and decrease mixed air temperature to maintain SAT at setpoint, but, when DX cooling is running, also may modulate the Outside Air damper closed to increase mixed air temperature (use more return air) and thus add load on the DX coil to maintain SAT at setpoint (“economizer loading”). This represents a trade-off between energy and compressor cycling.

CONTROL OF COMPRESSORS WITH ECONOMIZER

TURNING ON OF COMPRESSOR #1: Never operate compression if the Economizer can maintain the SAT setpoint with free cooling. If no compressors are on, and the economizer controller is saturated High, i.e. the economizer is 100% open and can no longer maintain the SAT setpoint by just free cooling, the control will:

The same staging sequence is used for the remaining compressor (see below). Note that the standard 5 minute delay before monitoring SAT after a compressor is turned on, or off, applies here also.

TURNING ON COMPRESSOR #2: If the economizer controller is saturated High, i.e. the economizer is 100% open while one or more compressors are running and the control can no longer maintain the active SAT setpoint requested by the zone control, the control will turn on compressor # 2:

NOTE: The standard 5 minute delay before monitoring SAT after a compressor is turned on or off.

The highest numbered running compressor is turned off when the economizer controller is saturated Low.

This method of turning compression off is considered better than using the Excessive SAT Control - turning a compressor OFF only if SAT reaches its specified trip point. If that method was used and the Excessive SAT Control was not selected, there would be no means for turning compressors off.

NOTE: The compressors also will be turned off when the zone temperature control is satisfied.

A situation may arise when in Economizer Mode and one or more compressors are required in addition to full available free cooling in order to maintain the SAT setpoint, but Cooling Lockout on OAT prevents the compressors use. This situation may arise when the SAT setpoint is set very close to, or even below the temperature set for Cooling Lockout on OAT - a relatively unusual case. If the OAT then increases above the lockout setting while the call for several compressors exists, the compressors will turn on with a delay between compressors.

ECONOMIZER LOADING OPTION - This is a user programmable option. It is automatically disabled if the unit does not use an economizer. The on/off programming choice is common to both cooling and heating. The default setting is ON. This programmable "Economizer Loading" function is used only outside the normal Economizer operation.

During the Economizer operation, the "Loading" function is always used and is an integral part of the Economizer control algorithm.

ECONOMIZER LOADING OPTION IN COOLING: In cooling, this function causes changes in mixed air temperature, as

modulated by the economizer dampers, in order to change SAT and keep it at SAT setpoint when only compressor #1 is running. This makes a trade-off between energy and compressor cycling and minimizes cycling of compressor #1. The loading is done by the same type of PI control algorithm as used in the normal Economizer operation.

The algorithm will be activated to do this function in following conditions:

- Economizer is "not suitable" (i.e. we are not in a normal Economizer mode)
- The programmable option "Economizer Loading to Control SAT" is ON
- Only compressor #1 is running

The control algorithm in this case has the capability of automatically change from direct to reverse acting in response to difference between OAT and RAT. When OAT is less than RAT, the algorithm is direct acting, the algorithm changes to reverse acting when RAT is less than OAT. This way, the "loading" of the DX coil is correctly done with return, or outdoor air, as appropriate, and there is no need to activate this "loading" function only at higher outdoor air temperatures (e.g. OAT > 60°F).

The algorithm controls SAT to its specified setpoint in control modes where no SAT setpoint is specified (such as in Excessive SAT control state in cooling), to a fixed temperature deadband of 50°F to 55°F.

NOTE: As opposed to the PI algorithm used in economizer control, the PI algorithm used here for economizer loading function does not need to utilize the High saturation state for any additional control functions. Therefore no complications arise when switching between direct and reverse acting modes.

ECONOMIZER LOADING OPTION IN HEATING: In heating, this function uses additional outside air, as modulated by the economizer dampers, in order to decrease SAT when only the first stage of heating is running and keep the SAT below the programmed "Economizer Loading Setpoint in Heating". This prevents the heat section from cycling on its internal temperature limit safety switch, which is typically set about 10°F above the Economizer Loading Setpoint. A need for economizer loading arises in Communicating Zoning System applications ("VVT" systems) using supply air bypass when heating load in the zones is low and a large amount of hot supply air is bypassed back into return and mixed air temperature is very high. Economizer loading may also be needed when supply air flow across the heat exchanger is lower than expected (e.g. wrong setting of fan speed, plugged air filters). A secondary benefit of economizer loading is an improvement in comfort as the supply air temperature is more stable and cycling of the unit is minimized.

The economizer loading minimizes cycling of heating stage #1 and makes a trade-off between energy and the benefits described above.

The Economizer Loading in heating option requires a SAT sensor that can sense SAT in heating mode. A sensor placed downstream of the heating stages. Such a sensor is provided only as a field-installed accessory, on units equipped with heating stages. The SAT sensor that is factory-installed can be used for cooling mode only. If a field-installed sensor is added, it will replace the factory-installed one and will then be usable for both heating and cooling modes.

The loading is done by the similar control algorithm as used in the normal economizer operation. The algorithm is activated to do this function in following conditions:

- Heating mode
- The programmable option "Economizer Loading to Control SAT" is ON
- Only heating stage #1 is running

The control algorithm in this case has a capability to automatically change from direct to reverse acting in response to difference between OAT and RAT. When OAT is less than RAT the algorithm is direct acting, when OAT is greater than RAT the algorithm is reverse acting.

This way, the "loading" of the heating stage is correctly done with return or outdoor air as appropriate, and there is no need to activate this "loading" function only in some specific range of outdoor air temperatures (e.g. OAT > programmed first heating stage trip point minus 50°F).

NOTE: Provision for direct vs. reverse acting switching is a feature of the control algorithm and the algorithm could be implemented as direct acting only in order to simplify implementation and save code space. The situation when economizer loading in heating is required while OAT greater than RAT is unlikely and if it should occur, the difference between OAT and RAT is negligible in comparison to the SAT control setpoint. The Economizer Loading function in heating controls SAT to a fixed temperature deadband of programmed "Economizer Loading Setpoint in Heating" and 5°F below this setpoint (the setpoint is programmable between 100°F - 195°F, default is 160°F).

In units that use hydronic heat, the Economizer Loading function may be enabled in order to be used for cooling. The on/off programming choice for this function is common to both cooling and heating. It is important to ensure that the programmed value of the "Economizer Loading Setpoint in Heating" is set higher than the value of "Hydronic Heat First Stage Setpoint". That assures, in normal conditions, the Economizer Loading function in heating is effectively disabled

and the economizer is closed to its minimum position during heating.

DEMAND VENTILATION

Demand Ventilation Operation control mode is self-configuring for the use of an Indoor Air Quality (IAQ) sensor - it will automatically detect that an IAQ sensor is connected and use it any time the IAQ sensor input indicates an IAQ level of 200 ppm, or higher.

NOTE: Due to the self-configuration operation, an error due to IAQ sensor failure can be indicated only in case the IAQ sensor fails during normal controller operation. If the IAQ sensor fails or is removed / disconnected during a power-off condition (e.g. during servicing of the unit while the control is not powered), the control will, on power up, self configure without the IAQ sensor and no error indication is provided.

When the IAQ sensor is detected as available, the control will use the Demand Ventilation Setpoint to control the IAQ levels in the building by modulating the Economizer more open.

The Demand Ventilation will operate in units equipped with an Economizer any time the option is turned ON and the control is in Occupied mode. The Demand Ventilation Operation is applicable in heating or cooling mode and will modulate the Economizer damper, if necessary, from its programmed minimum position or from its modulated position as defined in the Economizer Operation section.

An appropriate control algorithm is used to accomplish this function. This algorithm is a "step-and-wait" type, with the step size calculated as a function of offset between the Demand Ventilation Setpoint and the current IAQ level, and with a fixed "wait", or sampling time. This algorithm is activated whenever the IAQ level exceeds the setpoint and will override the economizer position more open, as needed, up to a pre-programmed Maximum Economizer Position for Demand Ventilation. The algorithm is deactivated, and the previous, normal mode of economizer position control resumes when the IAQ level becomes 50 ppm lower than the setpoint.

The programmed "Maximum Economizer Position for Demand Ventilation" is used to minimize the possibility that the Demand Ventilation may open the Economizer damper too much, such that at high OA temperatures, even combined cooling output of all compressors would not provide sufficient cooling. As a rule of thumb, all compressors combined achieve approx. 20°F SAT decrease. Similarly, at fairly low OA temperatures, the combined output of all heating stages may not be able to provide sufficient heating. This Economizer max. position limit is simpler to implement than a closed loop SAT low-limit control that would operate with a programmed high-limit for cooling and a programmed low limit for heating.

NOTE: An added measure of protection against excessive SAT during Demand Ventilation Operation is provided by Supply Air Alarm Setpoint for Cooling and Supply Air Alarm Setpoint for Heating, and the control function associated with these setpoints (see the respective paragraphs in the Option Operation section earlier in this document).

SCHEDULING OPERATION

The Simplicity® Intelli-Comfort™ refers to its clock and internal calendar to perform scheduling operations.

COMPRESSOR STATUS MONITORING

Compressor status is monitored using three separate 24 VAC circuits that monitor: low pressure, high pressure, and Evaporator Freeze Thermostats. If any of the three safeties is in error, the trip is noted in the alarm history.

The Low Refrigerant Pressure Switch is Normally Open. When the compressor is off and refrigerant pressure equalized, the switch under normal conditions is expected to be closed. However, in cold ambient operation, it may stay open and close only after the compressor starts up.

If an error is detected for a compressor, that compressor's output is turned off. Note that the controller executes the application code once every 32ms, with a 30 second startup delay and 5 second minimum error time on low pressure. The control then declares a "Compressor Locked Out on Trip" alarm. The alarm is written to the Error History Buffer.

NOTE: The compressor lockout works as an override of the output of the staging algorithm for cooling control. For example, the cooling control may ask for compressor #2 which is locked out, and as this request does not generate additional cooling.

STATUS LED

The Status LED mounted on the controller PC board will flash faster than the once a second flash indicating an Alarm. You will need to connect a computer to pull out the specific Alarm.

FAILURE MODES AND DEFAULT OPERATION

ERROR HISTORIES

The control will store the latest five errors in a FIFO manner in EEPROM, for later display. As the control collects errors, it will overwrite the oldest error after the history buffer becomes full.

Following are errors that are entered into the error history buffer:

- Compressor locked out on safety chain trip
- Supply fan failure
- Heating SAT failure
- Cooling SAT failure
- SAT,RAT,OAT,IAQ, ST, or RH failure
- Dirty Filter alarm
- Bad Air Proving Switch

SENSOR FAILURES AND DEFAULT OPERATION

A failure of SAT RAT, OAT, IAQ, Space Temperature, or an outside or return air Relative Humidity sensor will generate a common error. A failure of the Duct Static or Building Pressure sensor will generate another common error. The errors will be indicated by a Status LED. The errors will be written to the Error History Buffer. In networked application, the error flag will be readable by the network. The error indication of a sensor failure will continue until the problem is corrected and will automatically terminate when the sensor is again detected as reliable. If the unit is shut down as a result of a sensor failure, the alarm must be reset after the sensor problem has been corrected, by resetting the controller, or reset command issued by the Front-end software.

SAT SENSOR

If the SAT sensor fails, the Economizer, excessive SAT control will be disabled. The Control will then continue a "limp along" operation under zone sensor control. RAT Sensor

If the RAT sensor fails, it will default to single enthalpy or Dry Bulb operation.

OAT SENSOR

UNITS WITHOUT ECONOMIZER: If the OAT sensor fails the control will not run any algorithm that requires that data.

UNITS WITH ECONOMIZER: All Economizer Operation will be disabled. This is because OAT sensor is the most essential sensor in determining availability of free cooling. Even if the unit is equipped with Outside RH sensor and controller could calculate Outdoor Enthalpy, the OAT sensor is still essential in that calculation. The Economizer will only modulate to the Minimum Position when the Fan is operating and the control is in Occupied Mode.

OUTSIDE AIR RELATIVE HUMIDITY SENSOR

If the OAH sensor fails, the control will only use the OAT sensor to determine if Free Cooling is available. The control will self-configure to Outside Temperature Method (see also Economizer Operation section earlier in this document).

RETURN AIR RELATIVE HUMIDITY SENSOR

The control will self-configure to Outside Enthalpy Operation.

SPACE TEMPERATURE SENSOR

When the space temperature sensor fails the control will check if the RAT sensor is present. If it has a RAT sensor, the control will use it as a backup and continue temperature control to the active space temperature setpoint. If there is no RAT Sensor, the control will shut down all outputs. If the detected sensor failure is a short circuit, the error can be declared only if the short persists for several minutes, in order to distinguish a sensor failure from a short caused by somebody pushing on Unoccupied Override button.

IAQ SENSOR

If the IAQ sensor fails, Demand Ventilation mode is de-activated.

SYSTEM ERRORS

HEATING SAT FAILURE

In Heating mode with all stages of heating energized, the SAT must drive above the Supply Air Alarm Setpoint for Heating within ten minutes or this SAT failure error will be activated. The error will be written to the Error History Buffer. In networked application, the error flag will be readable via the network.

COOLING SAT FAILURE

In Cooling mode and all stages of compression are energized, the SAT must drive below the Supply Air Alarm Setpoint for Cooling within ten minutes or this SAT failure error will be activated. The error will be written to the Error History

Buffer. In networked application, the error flag will be readable via the network.

SUPPLY FAN FAILURE

The conditions under which this failure is declared, and the follow-up actions of the control when this error occurs are described in a paragraph on Air Proving Switch Operation earlier in this document. The error will be written to the Error History Buffer. In networked application, the error flag will be readable via the network.

COMPRESSOR SAFETY CHAIN TRIP

The conditions under which this failure is declared, and the follow-up actions of the control when this error occurs are described in a paragraph on Compressor Status Monitoring earlier in this document. The error will be written to the Error History Buffer. In networked application, the error flag will be readable via the network.

DIRTY FILTER ALARM

The conditions under which this failure is declared, and the follow-up actions of the control when this error occurs are described in a paragraph on Dirty Filter Switch (DFS) option earlier in this document. The error will be written to the Error History Buffer. In networked application, the error flag will be readable via the network.

BAD AIR PROVING SWITCH ERROR

The conditions under which this failure is declared, and the follow-up actions of the control when this error occurs are described in a paragraph on Air Proving Switch Operation earlier in this document. The error will be written to the Error History Buffer. In networked application, the error flag will be readable via the network.