Source 1

REPLACEMENT PARTS

# 7.5, 10 Ton Indoor/Outdoor Split Systems
## FA & LA 090-120 / EA & HA 090-120

Supersedes: Nothing

035-18949-001 Rev. A (0602)

**Note: This is a non-comprehensive parts lists intended for stocking purposes for first production (style A) units only. It is not intended to replace the complete, comprehensive list with subsequent style changes.**

| | | | MODELS | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| PartNumber | Description | ELECTRICAL CODE | EA090C00A2AAA1A | EA090C00A2AAC1A | EA090C00A4AAA1A | EA090C00A4AAC1A | EA120C00A2AAA1A | EA120C00A2AAC1A | EA120C00A4AAA1A | EA120C00A4AAC1A | FA090C00A6AAA1A | FA120C00A6AAA1A | HA090C00A2AAA1A | HA090C00A2AAC1A | HA090C00A4AAA1A | HA090C00A4AAC1A | HA090C00A5AAA1A | HA090C00A5AAC1A | HA120C00A2AAA1A | HA120C00A2AAC1A | HA120C00A4AAA1A | HA120C00A4AAC1A | HA120C00A5AAA1A | HA120C00A5AAC1A | LA090C00A6AAA1A | LA120C00A6AAA1A |
| | | | QUANTITY PER UNIT | | | | | | | | | | | | | | | | | | | | | | | |
| 026-25573-706 | ACCUMULATOR | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| 026-35538-000 | ACCUMULATOR | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 063-87545-000 | ANGLE, RETURN AIR PANEL | | | | | | | | | | 2 | | | | | | | | | | | | | | 2 | |
| 026-34755-000 | ARM, MOTOR MOUNT | | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | | | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | | |
| 028-09573-000 | BELT, V A36 37.3 | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 | |
| 028-05438-000 | BELT, V A55 56.3 | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| **026-25380-000** | BLOWER, BELT DRIVE | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 026-25381-000 | BLOWER, BELT DRIVE | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 | |
| 073-20532-000 | BRACKET, LIQUID DISCHARGE | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-18661-000 | BRACKET, SERVICE VALVE | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-18664-000 | BRACKET, SERVICE VALVE | | | | | | 1 | 1 | 1 | 1 | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-21607-000 | BRACKET, TXV SUPPORT | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |
| 073-02008-000 | BRACKET, VALVE | | 1 | 1 | 1 | 1 | | | | | | | 2 | 2 | 2 | 2 | 2 | 2 | | | | | | | | |
| 023-10745-000 | CAP, SEAL 1/4 FLARE | | 1 | 1 | 1 | 1 | 1 | 2 | 1 | 2 | | 1 | 4 | 3 | 4 | 3 | 4 | 3 | 2 | 2 | 2 | 2 | 2 | 2 | 1 | |
| 023-11018-000 | CAP, SEAL,1/4 F | | | | | 3 | 1 | 2 | 1 | 2 | | | | | | | | | | | | | | | | |
| 028-05014-000 | CAP, SEALING | | | | | | | | | | | 2 | | | | | | | | | | | | | | 2 |
| 024-20046-000 | CAPACITOR, RUN,10.0/MFD,370V | 1RC | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | | 1 | 1 | 1 | 1 | | | | | | | | | | |
| 024-20046-000 | CAPACITOR, RUN,10.0/MFD,370V | 2RC | | | | | | | | | | | 1 | 1 | 1 | 1 | | | 2 | 2 | 2 | 2 | | | | |
| 024-31404-000 | CAPACITOR, RUN,10/440 | 1RC | | | | | | | | | | | | | | | 2 | 2 | | | | | | | | |
| 024-31404-000 | CAPACITOR, RUN,10/440 | 1RC | | | | | | | | | | | | | | | | | | | | | 2 | 2 | | |
| 073-18737-000 | CHANNEL,MOTOR SUPPORT | | | | | | | | | | 1 | 1 | | | | | | | | | | | | | 1 | 1 |
| 024-27583-000 | CIRCUIT BREAKER | 2CB | | | | | 1 | 1 | | | | | | | | | | | 1 | 1 | | | | | | |
| 024-31976-000 | CIRCUIT BREAKER | CB | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | |
| 024-31976-000 | CIRCUIT BREAKER | 1CB | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | | |
| 373-24479-151 | COIL, COND,TECHNI (FRMD) | | | 1 | | 1 | | | | | | | | | | | | | | | | | | | | |
| 373-23377-200 | COIL, COND.FLAT & COATED | | | | | | | | | | | | | 1 | | 1 | | 1 | | | | | | | | |
| 373-23377-000 | COIL, CONDENSER | | | | | | | | | | | | 1 | | 1 | | 1 | | | | | | | | | |
| 373-24479-101 | COIL, CONDENSER (FORMED) | | 1 | | 1 | | | | | | | | | | | | | | | | | | | | | |
| 373-02007-012 | COIL, CONDENSER, FORMED | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |
| 373-24629-100 | COIL, CONDENSER, LH, FRMD | | | | | | 1 | | 1 | | | | | | | | | | | | | | | | | |
| 373-24629-150 | COIL, CONDENSER, LH, FRMD | | | | | | | 1 | | 1 | | | | | | | | | | | | | | | | |
| 373-24541-100 | COIL, CONDENSER, LH, FRMD | | | | | | | | | | | | | | | | | | 1 | | 1 | | 1 | | | |
| 373-24541-150 | COIL, CONDENSER, LH, FRMD | | | | | | | | | | | | | | | | | | | 1 | | 1 | | 1 | | |
| 373-24540-100 | COIL, CONDENSER, RH, FRMD | | | | | | | | | | | | | | | | | | 1 | | 1 | | 1 | | | |
| 373-24628-100 | COIL, CONDENSER, RH, FRMD | | | | | | 1 | | 1 | | | | | | | | | | | | | | | | | |
| 373-24628-150 | COIL, CONDENSER, RH, FRMD | | | | | | | 1 | | 1 | | | | | | | | | | | | | | | | |
| 373-24540-150 | COIL, CONDENSER, RH, FRMD | | | | | | | | | | | | | | | | | | | 1 | | 1 | | 1 | | |
| 373-24564-000 | COIL, EVAPORATOR | | | | | | | | | | | | | | | | | | | | | | | | | 1 |
| 373-24669-000 | COIL, EVAPORATOR | | | | | | | | | | | 1 | | | | | | | | | | | | | | |
| 373-09473-001 | COIL, EVAPORATOR | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 373-24001-010 | COIL, EVAPORATOR | | | | | | | | | | | | | | | | | | | | | | | | 1 | |
| 373-02007-010 | COIL, FLAT,LH,OUTER | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |
| 015-03416-004 | COMPRESSOR, H20R943DBEA | | | | | | | | | | | | | | | 1 | | | | | | | | | | |
| 015-03417-004 | COMPRESSOR, H20R943DBFA | | | | | | | | | | | | | | | | 1 | 1 | | | | | | | | |
| 015-03412-004 | COMPRESSOR, H20R943DBLA | | 1 | 1 | | | | | | | | | 1 | 1 | | | | | | | | | | | | |
| 015-03165-004 | COMPRESSOR, ZR125KCTF5 | | | | | | 1 | 1 | | | | | | | | | | | 1 | 1 | | | | | | |
| 015-03169-004 | COMPRESSOR, ZR125KCTFD | | | | | | | | 1 | 1 | | | | | | | | | | | 1 | 1 | | | | |
| 015-03177-004 | COMPRESSOR, ZR125KC-TFE | | | | | | | | | | | | | | | | | | | | | | 1 | 1 | | |
| 024-27531-000 | CONTACTOR | 2M | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 024-19608-000 | CONTACTOR, ELEC,25 AMP | 2M | 1 | 1 | 1 | 1 | | | | | | | 1 | 1 | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 024-25955-000 | CONTACTOR, ELEC,30 AMP | 1M | | | 1 | 1 | | | 1 | 1 | | | | | | | | | | | 1 | 1 | 1 | 1 | | |
| 024-25955-000 | CONTACTOR, ELEC,30 AMP | 10M | | | | | | | | | 1 | 1 | | | | | | | | | | | | | 1 | 1 |
| 024-25844-000 | CONTACTOR, ELEC,40 AMP | 1M | 1 | 1 | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 024-25846-700 | CONTACTOR, ELEC,50 AMP | 1M | | | | | 1 | 1 | | | | | | | | | | | 1 | 1 | | | 0 | | | |
| 031-01259-001 | CONTROL MODULE, COMPR | SC | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 031-09104-000 | CONTROL, DEFROST | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| **025-37369-000** | CONTROL, PRESS | PS | 1 | 1 | 1 | 1 | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| **025-37480-000** | CONTROL, PRESS | PS | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 025-17620-022 | CONTROL, PRESS | HP | | | | | 1 | 1 | 1 | 1 | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 025-17620-013 | CONTROL, PRESS,RFG 7/ 22 | LP | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| 025-17620-718 | CONTROL, PRESS,RFG 7/ 22 | LP | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 025-17620-020 | CONTROL, PRESS,RFG 23/ 38 | LP | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 025-32785-000 | CONTROL, PRESS,RFG,405/265 | HP | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 025-17620-029 | CONTROL, PRESS,RFG430/310 | HP | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| 025-37383-000 | CONTROL, TEMP | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| **025-37481-000** | CONTROL, TEMP | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| **025-37482-000** | CONTROL, TEMP | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |

New replacement parts shown in **bold face** at the printing of the Parts List code dated (0602).

| PartNumber | Description | ELECTRICAL CODE | MODELS | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | EA090C00A2AAA1A | EA090C00A2AAC1A | EA090C00A4AAA1A | EA090C00A4AAC1A | EA120C00A2AAA1A | EA120C00A2AAC1A | EA120C00A4AAA1A | EA120C00A4AAC1A | FA090C00A6AAA1A | FA120C00A6AAA1A | HA090C00A2AAA1A | HA090C00A2AAC1A | HA090C00A4AAA1A | HA090C00A4AAC1A | HA090C00A5AAA1A | HA090C00A5AAC1A | HA120C00A2AAA1A | HA120C00A2AAC1A | HA120C00A4AAA1A | HA120C00A4AAC1A | HA120C00A5AAA1A | HA120C00A5AAC1A | LA090C00A6AAA1A | LA120C00A6AAA1A |
| 025-23280-000 | CONTROL, TEMP | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 025-31994-000 | CONTROL, TEMP,DEFROST | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| 022-02475-000 | CORE, V PORT /SCHRAEDER | | 2 | 2 | 2 | 2 | 2 | 4 | 2 | 4 | | 1 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 1 | |
| **025-37462-000** | DISTRIBUTOR | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 022-09007-000 | DISTRIBUTOR ASSY, 10 TUBE | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |
| 022-08968-000 | DISTRIBUTOR ASSY, 12 TUBE | | 1 | 1 | 1 | 1 | | | | | 1 | | | | | | | | | | | | | | | |
| **025-37370-000** | DISTRIBUTOR ASSY. | | | | | | | | | | | | | | | | | | | | | | | | 1 | |
| 026-25559-000 | DISTRIBUTOR, 2 FEED,.625ID | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 2 | | |
| 026-38482-000 | FAN, PROP,24DIA,3BL,26DEG | | 2 | 2 | 2 | 2 | | | | | | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | |
| 026-38453-000 | FAN, PROP,24DIA,3BL,30DEG | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |
| 026-03611-000 | FILTER, AIR TROWA 1X16X25 | | | | | | | | | | 4 | | | | | | | | | | | | | | 4 | |
| 026-03610-000 | FILTER, AIR TROWA 1X20X20 | | | | | | | | | | | 6 | | | | | | | | | | | | | | 6 |
| 026-34506-000 | FILTER/DRIER | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 026-25596-001 | FILTER/DRIER, LIQUID LINE | | 1 | 1 | 1 | 1 | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |
| 026-35475-000 | FILTER/DRIER, SOLID CORE | | | | | | | | | | 1 | 1 | | | | | | | | | | | | | | |
| 063-70833-000 | FRAME, RETURN AIR PANEL | | | | | | | | | | 2 | | | | | | | | | | | | | | 2 | |
| 028-12342-700 | GROMMET, COMP,DUAL | | | | | | 4 | 4 | 4 | 4 | | | | | | | | | 4 | 4 | 4 | 4 | 4 | 4 | | |
| 028-04805-000 | GROMMET, PVC,1.250ID/1.562 | | | | | | | | | | | | 2 | 2 | 2 | 2 | 2 | 2 | | | | | | | 1 | |
| 028-04873-000 | GROMMET, PVC,1.250ID/1.562 | | | | | | 2 | 2 | 2 | 2 | 1 | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | 1 |
| 028-04859-000 | GROMMET, PVC,1.625ID/1.937 | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 | |
| 028-04791-000 | GROMMET, PVC,2.125ID/2/625 | | | | | | | | | | | | | | | | | | | | | | | | 1 | |
| 028-04698-000 | GROMMET, PVC,2.375ID/2/875 | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 1 | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 028-04699-000 | GROMMET, PVC,2.625ID/3.125 | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | 1 |
| **028-13344-000** | GROMMET, RUBBER | | 4 | 1 | 4 | 1 | | | | | | | 4 | 4 | 4 | 4 | 4 | 4 | | | | | | | | |
| 026-31429-000 | GUARD, FAN | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | |
| 373-24566-000 | HEADER | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 373-23377-002 | HEADER, CONDENSER | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 373-23377-001 | HEADER, CONDENSER | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 373-24479-050 | HEADER, CONDENSER | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| 373-24629-050 | HEADER, DISCHARGE | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 373-24540-060 | HEADER, DISCHARGE | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 373-24541-060 | HEADER, DISCHARGE | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 373-24540-050 | HEADER, DISCHARGE | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 373-24541-050 | HEADER, DISCHARGE | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 373-24628-050 | HEADER, DISCHARGE | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 373-24001-020 | HEADER, EVAPORATOR | | | | | | | | | | | | | | | | | | | | | | | | 1 | |
| 373-09473-050 | HEADER, EVAPORATOR | | | | | | | | | | 3 | | | | | | | | | | | | | | | |
| 025-37399-240 | HEATER, CRCK, 240-1-60V | | 1 | 1 | | | | | | | | | 1 | 1 | | | | | | | | | | | | |
| 025-37399-480 | HEATER, CRCK, 480-1-60V | | | | 1 | 1 | | | | | | | | | 1 | 1 | | | | | | | | | | |
| 025-37399-575 | HEATER, CRCK, 575-1-60V | | | | | | | | | | | | | | | | 1 | 1 | | | | | | | | |
| 025-33474-240 | HEATER, CRCK,240/1/60V | | | | | | 1 | 1 | | | | | | | | | | | 1 | 1 | | | | | | |
| 025-33474-480 | HEATER, CRCK,480/1/60V | | | | | | | | 1 | 1 | | | | | | | | | | | 1 | 1 | | | | |
| 025-33474-575 | HEATER, CRCK,575/1/60V | | | | | | | | | | | | | | | | | | | | | | 1 | 1 | | |
| 028-04210-000 | ISOLATOR, NEOPRENE .562HOL | | 16 | 16 | 16 | 16 | 0 | 0 | 0 | 0 | | | 16 | 16 | 16 | 16 | 16 | 16 | | | | | | | | |
| 028-04209-000 | ISOLATOR, RUBBER 1.000HOLE | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | |
| 025-21798-000 | LUG, ELECTRICAL | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 024-19623-018 | MOTOR, BLOWER,1.5HP,208/460 | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 | |
| 024-19623-016 | MOTOR, BLOWER,2.0HP,200/460 | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 024-31946-004 | MOTOR, FAN 3/4 HP 575-1-60 | | | | | | | | | | | | | | | | 2 | 2 | | | | | 2 | 2 | | |
| 024-31946-006 | MOTOR, FAN,3/4HP,230-1-60 | | 2 | 2 | | | 1 | 1 | | | | | 2 | 2 | | | | | 2 | 2 | | | | | | |
| 024-31946-005 | MOTOR, FAN,3/4HP,460-1-60 | | | | 2 | 2 | | | 2 | 2 | | | | | 2 | 2 | | | | | 2 | 2 | | | | |
| 026-34756-000 | MOTOR, MOUNT,BELLY | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | |
| 363-70814-002 | PAN, CONDENSATE | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 363-70872-001 | PAN, CONDENSATE | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 063-70772-000 | PAN, CONDENSATE | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 363-70857-000 | PANE, L END COIL SECT | | | | | | | | | | 0 | 3 | | | | | | | | | | | | | | |
| 363-70871-000 | PANEL, REAR | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 073-02131-001 | PANEL, ACCESS | | 2 | 2 | 2 | 2 | | | | | | | 2 | 2 | 2 | 2 | 2 | 2 | | | | | | | | |
| 073-21610-000 | PANEL, ACCESS | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |
| 073-24535-000 | PANEL, ACCESS COMPRESSOR | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-02132-001 | PANEL, ACCESS, CONTROLS | | 1 | 1 | 1 | 1 | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 073-24534-000 | PANEL, ACCESS, HEAT | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 363-84063-000 | PANEL, BLOWER DISCH ASSY | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 363-70937-000 | PANEL, BOTTOM & FRAME ASSY | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 063-70847-000 | PANEL, ENCLOSURE | | | | | | | | | | | 4 | | | | | | | | | | | | | | 4 |
| 363-70856-000 | PANEL, END SW & INS | | | | | | | | | | | | | | | | | | | | | | | | | |
| 363-70856-001 | PANEL, END SW & INS | | | | | | | | | | | 1 | | | | | | | | | | | | | | |
| 363-70854-000 | PANEL, END VERT COIL INS | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 073-22537-000 | PANEL, FRONT | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-23301-002 | PANEL, FRONT PIPING | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 363-70883-000 | PANEL, FRONT UPPER | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 073-24626-000 | PANEL, GUARD FAN LH | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-24627-000 | PANEL, GUARD FAN RH | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-02130-000 | PANEL, POWER | | 1 | 1 | 1 | 1 | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 363-70867-000 | PANEL, REAR | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 363-70875-000 | PANEL, SIDE LH | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 363-70881-000 | PANEL, SIDE RH LOWER FRNT | | | | | | | | | | 1 | | | | | | | | | | | | | | | |

New replacement parts shown in **bold face** at the printing of the Parts List code dated (0602).

| PartNumber | Description | ELECTRICAL CODE | MODELS | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | EA090C00A2AAA1A | EA090C00A2AAC1A | EA090C00A4AAA1A | EA090C00A4AAC1A | EA120C00A2AAA1A | EA120C00A2AAC1A | EA120C00A4AAA1A | EA120C00A4AAC1A | FA090C00A6AAA1A | FA120C00A6AAA1A | HA090C00A2AAA1A | HA090C00A2AAC1A | HA090C00A4AAA1A | HA090C00A4AAC1A | HA090C00A5AAA1A | HA090C00A5AAC1A | HA120C00A2AAA1A | HA120C00A2AAC1A | HA120C00A4AAA1A | HA120C00A4AAC1A | HA120C00A5AAA1A | HA120C00A5AAC1A | LA090C00A6AAA1A | LA120C00A6AAA1A |
| 363-70887-000 | PANEL, SIDE RH LOWER REAR | | | | | | | | | | 0 | | | | | | | | | | | | | | 1 | |
| 363-70888-000 | PANEL, SIDE RH LOWER REAR | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 363-70880-000 | PANEL, SIDE RH UPPER | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 363-70982-000 | PANEL, TOP DISCH | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 | |
| 073-24543-000 | PANEL, TOP ELECTRIC BOX | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-02292-001 | PLATE, ACCESS .500 DIA | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 073-20520-000 | POST, CENTER FRONT | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-24545-000 | POST, CENTER REAR | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-21656-000 | POST, CENTER REAR | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-21614-000 | POST, CORNER | | | | | | 4 | 4 | 4 | 4 | | | | | | | | | | | | | | | | |
| 073-18660-000 | POST, CORNER REAR | | 2 | 2 | 2 | 2 | | | | | | | 2 | 2 | 2 | 2 | 2 | 2 | | | | | | | | |
| 073-19463-000 | POST, CORNER,LF | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-18658-000 | POST, CORNER,LH,FRONT | | 1 | 1 | 1 | 1 | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 073-20541-000 | POST, CORNER,REAR | | | | | | | | | | | | | | | | | | 2 | 2 | 2 | 2 | 2 | 2 | | |
| 073-19464-000 | POST, CORNER,RF | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-18659-000 | POST, CORNER,RH,FRONT | | 1 | 1 | 1 | 1 | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 073-24625-000 | POST, FRONT, CENTER | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-21611-000 | POST, FRONT,PIPING | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 062-30549-000 | PROTECTOR, RAINSHILED | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | |
| 073-02133-000 | RAIL, BASE | | 2 | 2 | 2 | 2 | | | | | | | 2 | 2 | 2 | 2 | 2 | 2 | | | | | | | | |
| 073-20613-000 | RAIL, BASE FRONT | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-20614-000 | RAIL, BASE REAR | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-21608-000 | RAIL, BASE, FRONT | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-21609-000 | RAIL, BASE,BACK | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-02134-000 | RAIL, END | | 2 | 2 | 2 | 2 | | | | | | | 2 | 2 | 2 | 2 | 2 | 2 | | | | | | | | |
| 073-05143-001 | RAIL, END W/SLOTS | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-05143-002 | RAIL, END WO/SLOTS | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 024-19621-000 | RELAY, CONT 24V /60HZSPDT | RW | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| 024-24102-000 | RELAY, CONT 24V50/60HZ3PDT | 1RY | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 024-11090-000 | RELAY, CONT 24V50/60HZDPDT | RVS | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 024-21678-000 | RELAY, CONT 24V50/60HZSPDT | RA | | | | | | | | | | | | | | | | | 1 | 1 | | | | | | |
| 073-19460-000 | ROOF, CONDENSER | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 073-21662-000 | ROOF, CONDENSER | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 073-19373-000 | ROOF, CONDENSER, 10 & 12 T | | 1 | 1 | 1 | 1 | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| **026-35513-000** | SCREEN, 4.00X8.00 .023 | | | | | | | | | | | 3 | | | | | | | | | | | | | | 3 |
| 028-12496-000 | SHEAVE, FXD,1GRV,1.000BORE | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 | |
| 028-10555-000 | SHEAVE, FXD,1GRV,1.000BORE | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 028-04764-000 | SHEAVE, VAR,1GRV, .875BORE | | | | | | | | | | 1 | 1 | | | | | | | | | | | | | 1 | 1 |
| 022-08017-000 | STEM, VALVE 1/4 OD TUBE | | 3 | 3 | 3 | 3 | 2 | 2 | 2 | 2 | 2 | 1 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 1 | 1 |
| 063-71596-000 | SUPPORT, BAFFLE | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 | |
| 063-70986-000 | SUPPORT, BLOWER | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 | |
| 363-70865-000 | SUPPORT, BLOWER K2EU&F1EH | | | | | | | | | | 2 | | | | | | | | | | | | | | | |
| 363-71020-000 | SUPPORT, BLOWER LH | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 363-71021-000 | SUPPORT, BLOWER RH | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 063-70806-000 | SUPPORT, DRAIN | | | | | | | | | | | 2 | | | | | | | | | | | | | | 2 |
| 363-71283-000 | SUPPORT, MOTOR | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| 073-18736-000 | SUPPORT, MOTOR 1.5,2,3 HP | | | | | | | | | | 1 | 1 | | | | | | | | | | | | | 1 | 1 |
| **025-32770-000** | TERM BLOCK | 3TB | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 025-19829-000 | TERM BLOCK, 10P,150V, 20A | 2TB | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | | | | | | 1 | 1 |
| 025-20710-000 | TERM BLOCK, 3P,600V,175A | 1TB | | | | | 1 | 1 | 1 | 1 | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 025-08979-000 | TERM BLOCK, 4P,300V, 20A | 1TB | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | |
| 025-08979-000 | TERM BLOCK, 4P,300V, 20A | 2TB | | | | | | | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | | |
| 025-27729-000 | TRANSF, 575V/24V 75A | 1T | | | | | | | | | | | | | | | 1 | 1 | | | | | 1 | 1 | | |
| 025-25974-000 | TRANSF, .075 KVA 460PRI-24 | 1T | | | 1 | 1 | | | 1 | 1 | | | | | 1 | 1 | | | | | 1 | 1 | | | | |
| 025-25973-000 | TRANSF, .075KVA 208/230-24 | 1T | 1 | 1 | | | 1 | 1 | | | | | 1 | 1 | | | | | 1 | 1 | | | | | | |
| 025-37378-000 | TRANSF, 150K VA 208/230-24 | 2T | | | | | 1 | 1 | | | | | | | | | | | 1 | 1 | | | | | | |
| 022-06803-000 | VALVE, ANGLE | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 022-06802-000 | VALVE, ANGLE | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| 022-09009-000 | VALVE, ANGLE | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 022-05251-000 | VALVE, CHECK BALL 5/8 FEM | | 1 | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 1 | 1 | | | | | | | | | | | | | | |
| 025-33426-000 | VALVE, EXPANSION | | | | | | | | | | 1 | | | | | | | | | | | | | | | |
| 022-06850-002 | VALVE, LIQ 5/8 SWT | | 1 | 1 | 1 | 1 | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | |
| 025-33379-000 | VALVE, REVERSING | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| 025-37063-000 | VALVE, REVERSING | | | | | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
| 022-08969-000 | VALVE, STEM,BULKHEAD | | 2 | 2 | 2 | 2 | 2 | 4 | 2 | 4 | | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | |
| 022-08997-000 | VALVE, SUCTION | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| 022-08919-700 | VALVE, THERM. EXP. | | | | | | 2 | 2 | 2 | 2 | | | | | | | | | | | | | | | | |
| **022-09015-000** | VALVE, THERMO-EXPN | | | | | | | | | | | 1 | | | | | | | | | | | | | | 1 |
| **022-09013-000** | VALVE, TXV | | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| **022-09012-000** | VALVE, TXV | | | | | | | | | | | | | | | | | | | | | | | | 1 | |

New replacement parts shown in **BOLD FACE** type at the first printing of Parts List code dated (0602).